



BEGINNER ELECTROSEX KIT



Instruction Manual MI800

The Beginner Electrosex Kit can be dangerous if it is not used properly. All users must read the following operating instructions and understand all warnings before using this product. By using this product, the purchaser and any recipient involved acknowledges all possible risks, and accepts all terms and conditions outlined herein.

INTRODUCTION

The Beginner Electrosex Kit provides the latest innovation in erotic stimulation. Electrosex devices and accessories provide unique sensations when short electrical currents are passed under the skin. Beginning with teasingly low levels, then increasing the intensity, many users have reported that the inner electric vibrations have helped them achieve hands-free orgasms! There are additional interchangeable accessory options, so once you've mastered your Beginner Electrosex Kit, you'll be ready to add on all new options for electronic stimulation.

CAUTION

Electrosex stimulation is only for healthy, consenting adults who understand all operating procedures and warnings. Consult a physician if you have a history of medical complications or any questions or concerns. If you do not accept these warnings, or cannot safely use this product, return this unused Beginner Electrosex Kit to your dealer for a refund.

DO NOT USE THE BEGINNER ELECTROSEX KIT IF ANY OF THE FOLLOWING APPLY TO YOU:

- If you have any type of electronic implanted device, such as a pacemaker, drug pump, or defibrillator.**
- If you have a history of health complications, including (but not limited to) the following: seizures, heart disease, heart attack, epilepsy, nervous system disorders, brain disorders, stroke, serious skin problems, or any similar medical condition.**
- If you are currently pregnant, or may be pregnant.**
- If you are a minor, under the age of 18 years old.**

IMPORTANT WARNINGS AND INSTRUCTIONS:

- Never attach electrosex adhesive pads or accessories on or near the heart, neck, or head, as electrical currents passed through these areas can be fatal.**
- Always use your Beginner Electrosex Kit devices below the waist.**

- **Do not touch adhesive pads with your fingertips unless the power unit is turned off. Electric currents passed through these areas may be potentially dangerous.**
- **Always start at the lowest intensity level and comfortably work your way up. Sudden high levels of electrical currents can cause involuntary muscle contractions which can be painful or dangerous. Test the device first on yourself until you are familiar with it's operation procedures and intensity levels before using on someone else.**
- **Ensure that the power unit is turned off before attaching or removing the adhesive pads or accessories.**
- **When attaching the adhesive pads make sure that at least 0.5 square inches (3.2 sq. cm) of surface area is against the skin.**
- **Do not use adhesive pads or accessories on or over any type of body piercing.**
- **Do not use adhesive pads that contain lead or any other type of toxic material.**
- **Never use The Electrosex Beginner Kit on anyone who is asleep, or otherwise unable to respond or remove the attachments in the event that pain or a medical problem occurs.**
- **Do not use the Beginner Electrosex Kit more than 12 minutes per session and 3 hours per week.**
- **Never use any of your electrosex devices or power unit near water or wet conditions.**
- **Never use while operating a motor vehicle or heavy machinery.**
- **For external use only, do not place adhesive pads inside the vagina or anus.**
- **Keep all parts and accessories out of children's reach.**
- **Never use the Beginner Electrosex Kit to treat a medical condition.**

POSSIBLE SIDE AFFECTS:

Discontinue use and consult a physician immediately if any of these possible side affects become persistent.

- **Muscle soreness**
- **Skin irritation**
- **Severe Pain**
- **Numbness**
- **Any other unusual condition that develops and persists after the use of the Beginner Electrosex Kit.**

MAINTENANCE AND USAGE

- **Do not attempt to modify, repair, or disassemble your power unit or accessories.**
- **Only use accessories and attachments designed for the Beginner Electrosex Kit.**
- **Ensure that the lead wires are attached to the proper output sockets, installing them incorrectly may damage the unit.**
- **Only use an Alkaline 9 volt battery.**
- **Use only a damp cloth to clean the power unit and attachments. Never immerse in water or use harsh chemical cleaning fluids.**

USER AGREEMENT:

By using this product, the purchaser and any recipient user fully acknowledges and accepts the possible associated risks involved with using the Beginner Electrosex Kit. The purchaser and any recipient user has read and understands all warnings and operating procedures prior to usage.

LIMITATION OF LIABILITY:

The purchaser and/or recipient user is solely responsible for any possible risks, liability for loss, injury incurred, property damage, etc. as a result of use or misuse of the Zeus Beginner Electrosex kit or Zeus products. The manufacturer, Zeus, and any of their consultants, employees, related companies, affiliates, and agents are in no event responsible or liable to the purchaser or user claiming direct, indirect, incidental, consequential, or any other damage under potential theory of law as a result of use or misuse, even though the manufacturer is aware of such possible risks and damages. Please read all instructions and warnings before using the Beginner Electrosex Kit to avoid hazardous risks.

INDEMNITY:

The purchaser and/ or user agrees to indemnify, and will hold the manufacturer harmless of any and all claims, damages, causes of actions, demands, and any cost or expenses incurred (including attorney's fee's) that have arisen as a result of use or misuse of Zeus Beginner Electrosex Kit.

BINDING ARBITRATION:

All disputes relating to this agreement will be subject to final and binding arbitration. The purchaser and/ or user agrees that any claim or dispute that is to be filed as a result of the use or misuse of the Beginner Electrosex Kit will be filed with an objective, independent arbitrator. The purchaser and/ or user fully agrees that binding arbitration is the only action made to resolve a claim. The purchaser and/ or user waives their right to file a lawsuit in any civil court seeking remedies from the manufacturer or associated dealer, except in the event of enforcing a legally binding arbitration enforcement.

THE BEGINNER ELECTROSEX KIT INCLUDES:

- The power unit
- 4 adhesive pads
- 2 sets of lead wires
- Instructions
- 9 volt battery
- Bonus electrosex clamps

USA LIMITED WARRANTY

Zeus warrants all products against manufacturer defect for one year from the purchase date. The warranty does not cover the following:

- Misuse/ abuse
- Wear and tear
- Water damage
- Damage due to modifications
- Damage due to disassembly or parts that have been tampered with

Zeus and their related companies/ dealers/ associates or employees are not liable for any damages caused by the purchaser and/ or user as a result of use or misuse. Any form of reimbursement provided will not exceed the purchase price. Zeus will replace or possibly repair defective merchandise with the one year warranty period. A copy of your original invoice/ receipt is required for any warranty requests. The purchaser is responsible for all shipping costs and providing protective packaging materials. This warranty extends to the original purchaser only and is not transferable to any other users.

USING THE ELECTROSEK KIT

Amplitude Controls

Control knobs 1 and 2 adjust the stimulation intensity levels. The amplitude controls are marked from 1 to 8, indicating the increase in intensity levels of electrical currents. Each amplitude control also incorporates an ON/OFF switch. When either channel is turned on, the Green/Red indicator light will come on.

Indicator Light

When either channel is turned on, the green indicator light will be continuously lit. The red indicator light will follow the pulse rate and have a blinking/continuously lit indication display. The lower frequencies are indicated by a blinking light, and with higher frequencies it will continue to glow. When the battery is low or the unit has been operating over 20 minutes, the power indicator light will change from green to red, and the unit will shut itself off.

OUTPUT JACKS

CH-1 and CH-2 designate the output connections for channels 1 and 2.

BELT CLIP

This attaches the stimulator securely to your belt for secure mobility.

PULSE RATE CONTROL

This control regulates the frequency of stimulation from 2Hz to 150Hz pulses per second.

PULSE WIDTH CONTROL

This control adjusts the duration of each individual stimulation pulse width, from 50-250 microseconds.

MODE SELECTOR SWITCH

- M-Modulation Mode - Contraction 4 sec.
Relaxation 1 sec.
Pulse width and pulse rate are adjustable.**
- N-Normal Mode - Pulse width adjustable
50-250 microseconds
Pulse width adjustable 2-150Hz**
- B-Burst Mode - Contraction 0.2 sec.
Relaxation 0.2 sec.**

CONTROLS & INDICATOR

**CH-1 On/Off and
Amplitude Control**

**CH-2 On/Off and
Amplitude Control**



**CH-1 Output
Socket**

**CH-2 Output
Socket**

**CH-1 Output
Indicator**

Power Indicator

**CH-2 Output
Indicator**



Pulse Width Control

Pulse Rate Control

Mode Selector Switch

- Modulation
- Normal
- Burst

AUTO TIMER

For safety purposes, this unit will shut itself off after 20 minutes. To reset the timer, simply turn both amplitude controls to OFF then turn it back to the ON position.

The green light will change to red color after 20 minutes and the unit shut itself off. The green light will disappear when both the amplitude controls are set to off.

THE GREEN LIGHT

The green indicator will light up when the amplitude control is turned on, this green indicator will change to red after 20 minutes when the unit is about to shut itself off.

OPERATING PROCEDURE

The system is quite easy to operate and maintain if these instructions are followed.

- 1. Both amplitude controls 1 & 2 should be turned to off.**
- 2. Open battery compartment and insert 9 volt battery.**
- 3. Insert lead wire pins into adhesive pads so that no bare metal wires are exposed.**
- 4. Plug the pair of lead wires into the CH-1 and CH-2 output sockets.**
- 5. Place adhesive pads on clean, unbroken skin.**
- 6. Check and adjust the frequency, width, and mode selector controls to ensure they are set at the lowest values.**
- 7. Always increase the amplitude control slowly.**
- 8. Be sure the amplitude is off before applying or removing any units from skin or power unit.**